

WOOKIE SERIES

DMX CONTROL TABLE



| 3-CH Mode WOOKIE150G / 200R / 600B | | | | | |
|------------------------------------|---------|-----|---|-----|--------------------------------------|
| CH1 | Zooming | 000 | - | 127 | Manual pattern size |
| | | 128 | - | 255 | Loop zooming in / out |
| CH2 | | 000 | - | 255 | no function |
| | | 000 | - | 100 | Laser Off |
| CH3 | Mode | 101 | - | 155 | Sound Mode |
| | | 156 | - | 255 | Auto Mode with rising speed (0-100%) |

| 9-CH Mode WOOKIE150G / 200R / 600B | | | | | |
|------------------------------------|----------------|-----|---|-----|---|
| CH1 | Mode select | 000 | - | 063 | Laser Off |
| | | 064 | - | 127 | Auto Mode |
| | | 128 | - | 191 | Sound mode |
| | | 192 | - | 255 | DMX mode (CH2-CH8) |
| CH2 | | 000 | - | 255 | no function |
| CH3 | Pattern select | 000 | - | 255 | 32 Pattern (value 000 - 007, 008 - 015,...) |
| CH4 | Zooming | 000 | - | 127 | Manual pattern size |
| | | 128 | - | 255 | Loop zooming in / out |
| CH5 | X axis rolling | 000 | - | 127 | Manual rolling |
| | | 128 | - | 255 | Rolling speed |
| CH6 | Y axis rolling | 000 | - | 127 | Manual rolling |
| | | 128 | - | 255 | Rolling speed |
| CH7 | Z axis rolling | 000 | - | 127 | Manual rolling |
| | | 128 | - | 255 | Rolling speed |
| CH8 | X axis moving | 000 | - | 127 | Manual position |
| | | 128 | - | 255 | Horizontal moving speed |
| CH9 | Y axis moving | 000 | - | 127 | Manual position |
| | | 128 | - | 255 | Vertical moving speed |

| 3-CH Mode WOOKIE200RGY | | | | | |
|------------------------|---------|-----|---|-----|--------------------------------------|
| CH1 | Zooming | 000 | - | 127 | Manual pattern size |
| | | 128 | - | 255 | Loop zooming in / out |
| CH2 | Colours | 000 | - | 063 | Original colour |
| | | 064 | - | 127 | Red |
| | | 128 | - | 191 | Green |
| | | 192 | - | 255 | Yellow |
| CH3 | Mode | 000 | - | 100 | Laser Off |
| | | 101 | - | 155 | Sound Mode |
| | | 156 | - | 255 | Auto Mode with rising speed (0-100%) |

| 9-CH Mode WOOKIE200RGY | | | | | |
|-------------------------------|----------------|-----|---|-----|---|
| CH1 | Mode select | 000 | - | 063 | Laser Off |
| | | 064 | - | 127 | Auto Mode |
| | | 128 | - | 191 | Sound mode |
| | | 192 | - | 255 | DMX mode (CH2-CH8) |
| CH2 | Colours | 000 | - | 063 | Original colour |
| | | 064 | - | 127 | Red |
| | | 128 | - | 191 | Green |
| | | 192 | - | 255 | Yellow |
| CH3 | Pattern select | 000 | - | 255 | 32 Pattern (value 000 - 007, 008 - 015,...) |
| CH4 | Zooming | 000 | - | 127 | Manual pattern size |
| | | 128 | - | 255 | Loop zooming in / out |
| CH5 | X axis rolling | 000 | - | 127 | Manual rolling |
| | | 128 | - | 255 | Rolling speed |
| CH6 | Y axis rolling | 000 | - | 127 | Manual rolling |
| | | 128 | - | 255 | Rolling speed |
| CH7 | Z axis rolling | 000 | - | 127 | Manual rolling |
| | | 128 | - | 255 | Rolling speed |
| CH8 | X axis moving | 000 | - | 127 | Manual position |
| | | 128 | - | 255 | Horizontal moving speed |
| CH9 | Y axis moving | 000 | - | 127 | Manual position |
| | | 128 | - | 255 | Vertical moving speed |

| 3-CH Mode WOOKIE400RGB | | | | | |
|-------------------------------|---------|-----|---|-----|--------------------------------------|
| CH1 | Zooming | 000 | - | 127 | Manual pattern size |
| | | 128 | - | 255 | Loop zooming in / out |
| CH2 | Colours | 000 | - | 063 | Original colour |
| | | 064 | - | 095 | Red |
| | | 096 | - | 127 | Green |
| | | 128 | - | 159 | Blue |
| | | 160 | - | 191 | Yellow |
| | | 192 | - | 223 | Pink |
| | | 224 | - | 255 | Cyan |
| CH3 | Mode | 000 | - | 100 | Laser Off |
| | | 101 | - | 155 | Sound Mode |
| | | 156 | - | 255 | Auto Mode with rising speed (0-100%) |

| 9-CH Mode WOOKIE400RGB | | | | | |
|-------------------------------|----------------|-----|---|-----|---|
| CH1 | Mode select | 000 | - | 063 | Laser Off |
| | | 064 | - | 127 | Auto Mode |
| | | 128 | - | 191 | Sound mode |
| | | 192 | - | 255 | DMX mode (CH2-CH8) |
| CH2 | Colours | 000 | - | 063 | Original colour |
| | | 064 | - | 095 | Red |
| | | 096 | - | 127 | Green |
| | | 128 | - | 159 | Blue |
| | | 160 | - | 191 | Yellow |
| | | 192 | - | 223 | Pink |
| | | 224 | - | 255 | Cyan |
| CH3 | Pattern select | 000 | - | 255 | 32 Pattern (value 000 - 007, 008 - 015,...) |
| CH4 | Zooming | 000 | - | 127 | Manual pattern size |
| | | 128 | - | 255 | Loop zooming in / out |
| CH5 | X axis rolling | 000 | - | 127 | Manual rolling |
| | | 128 | - | 255 | Rolling speed |
| CH6 | Y axis rolling | 000 | - | 127 | Manual rolling |
| | | 128 | - | 255 | Rolling speed |
| CH7 | Z axis rolling | 000 | - | 127 | Manual rolling |
| | | 128 | - | 255 | Rolling speed |
| CH8 | X axis moving | 000 | - | 127 | Manual position |
| | | 128 | - | 255 | Horizontal moving speed |
| CH9 | Y axis moving | 000 | - | 127 | Manual position |
| | | 128 | - | 255 | Vertical moving speed |